

## Eaton Filtration Absorption Insert Important Installation Instructions

The Eaton Filtration Absorption Insert is the ultimate solution for an increased oil removal capacity.

The insert can be installed in most standard size O2 filter bags with SNAP-RING® and SENTINEL® ring collar and will provide for a multiple increase in dirt and oil removal capacity.

It is necessary to equip these elements once installed with a Stainless steel cover plate (PN: F671239) for optimal efficiency and capacity.

For an easier fit and removal of the element, the use of a Eaton Filtration straight-sided perforated plate basket (without the indent) is highly recommended.



### Step 1: Installation of the filter bag

Install the filter bag according to the standard installation instructions. Eaton Filtration recommends the use of a bag positioner for an optimal fit. The bag positioner will need to be removed once the bag is fitted.

### Step 2: Installation of the absorption insert

Insert the element in the filter bag by pushing the insert down with both hands at the centre core. The fitting in a SENTINEL ring bag will require some more force as you will need to pass by the handles of the ring. The top of the inserts needs to sit straight under the handles of the SENTINEL or SNAP-RING. Pull back the handles over the insert, so they are in reach for the extraction of the filter bag after use.

### Step 3: Put on the cover plate

Put the cover plate on top of the element with the centre pipe into the core of the element. The insert is installed and the housing can be closed.

For further info or questions, please contact your Eaton Filtration Representative.

#### Headquarters EUROPE, MIDDLE EAST and AFRICA

**Eaton Filtration GmbH**  
Auf der Heide 2  
D-53947 Nettersheim  
Germany

Tel. +49 2486 809 0  
Fax +49 2486 809 800  
info-filtration@eaton.com  
www.filtration.eaton.com

#### Telephone and Fax Numbers:

<b>Germany</b>	Tel. +49 (0) 2486 809 400	Fax +49 (0) 2486 809 500	<b>Belgium</b>	Tel. 0800 77 0 22	Fax 0800 77 0 23
<b>Export</b>	Tel. +49 (0) 2486 809 470	Fax +49 (0) 2486 809 570	<b>Luxembourg</b>	Tel. 800 2 42 98	Fax 800 2 42 99
<b>France</b>	Tel. +33 (0) 4 72 78 84 50	Fax +33 (0) 4 78 74 43 07	<b>Netherlands</b>	Tel. 0800 0 22 27 03	Fax 0800 0 22 26 95
<b>South Africa</b>	Tel. +27 (0) 11 791 43 31	Fax +27 (0) 11 791 05 83	<b>Italy</b>	Tel. 800 78 58 83	Fax 800 78 58 84
<b>UK</b>	Tel. +44 (0) 1206 848 350	Fax +44 (0) 1206 848 359	<b>Spain</b>	Tel. 900 98 49 15	Fax 900 98 49 14
<b>Austria</b>	Tel. 0800 29 36 89	Fax 0800 29 36 90			